

RWC5020x/5021x Application Program

Operation Manual

Version 1.331

October 2021



Contents

I. Getting Started	5
1.1 Download and Installation	6
1.2 Starting the Application	8
1.3 GUI Structure	10
1.3.1 Test function windows	11
1.3.2 Report function windows	11
II. Menus	13
2.1 PROJECT	14
2.1.1 Project Menu	14
2.1.1.1 New Project	14
2.1.1.2 Opening Project	15
2.1.1.3 Deleting Current Project	15
2.1.1.4 Project List	15
2.1.1.5 Opening Demo Project	16
2.1.2 DUT menu	16
2.1.2.1 New DUT	16
2.1.2.2 DEL Current DUT	17
2.2 SETUP	18
2.2.1 Connect RWC5020x/5021x	18
2.2.1.1 Open RWC5020x/5021x CONTROL PORT window	18
2.2.1.2 Connection via LAN	18
2.2.1.3 Connection via COM Port	19
2.2.2 Control DUT (ED)	20
2.2.2.1 Open PORT	21
2.2.2.2 Load User Commands	21
2.2.2.3 Show User Commands	21
2.2.2.4 Show DUT Monitor	22
2.2.2.5 Make Commands Template	22
2.2.3 Control DUT (GW)	23
2.2.4 Parameter Configuration	24
2.2.4.1 Protocol Parameters	25
2.2.4.2 RF Parameters	30
2.2.5 Remote by Other host	31
2.2.6 Utility Environment	33
2.3 UTILITY	37
2.3.1 DUT Control	37
2.3.1.1 How to Use	37
2.3.1.2 Verify Commands	38
2.3.1.3 Transmission Methods	38

2.3.2 RWC5020x/5021x Control	38
2.3.2.1 How to Use	39
2.3.2.2 Template	39
2.3.2.3 Sending commands	39
2.3.3 Screen Capture	40
2.4 ABOUT	41
2.4.1 Manual	41
2.4.2 Upgrade Notice	41
2.4.3 Licenses	42
2.4.4 About Application	43
2.4.5 Website	43
III. Test Functions	44
3.1 Pre-Certification Test	45
3.1.1 LoRaWAN® Pre-Certification	45
3.1.2 Operator Certification	46
3.1.3 Pre-Certification Test Items	47
3.1.3.1 Meaning of Text Colors	47
3.1.3.2 Selection and Test Parameter Configuration	47
3.1.3.3 Start Test	47
3.1.3.4 Control DUT	47
3.1.3.5 Test Result – Summary Table	48
3.1.3.6 Test Result – Detail Report	49
3.2 Performance Test	50
3.2.1 PER & POWER	50
3.2.1.1 Selection item	51
3.2.1.2 Test conditions	51
3.2.1.3 Protocol Parameters	55
3.2.1.4 Start/Stop Test	55
3.2.1.5 Tested Result	56
3.2.1.6 PER Performance test functionality condition	57
3.2.1.7 Viewing Remote commands	58
3.2.2 LBT TEST	58
3.2.2.1 Checking the connection to RWC2020A	58
3.2.2.2 Test Scenarios	58
3.2.2.3 Channel mode test	59
3.2.2.4 Burst mode test	60
3.2.2.5 Starting LBT test and result	60
3.2.3 NON-REGRESSION TEST	60
3.2.3.1 TX output power calibration	62
3.2.3.2 PER/RSSI/SNR	62
3.2.3.3 SENSITIVITY	63

3.2.3.4	Frequency error tolerance	64
3.2.3.5	CW immunity against the interferences with frequency offset.	65
3.2.3.6	Functionality condition	66
3.3	Link Analyzer	68
3.3.1	Saving link message	68
3.3.2	Payload editor	69
3.3.2.1	Sending Commands	69
3.3.2.2	Malfunction test	70
3.3.2.3	MAC Commander Parameters	71
3.3.3	Script editor	77
3.3.3.1	Adding commands	78
3.3.3.2	Moving commands	80
3.3.3.3	Deleting actions	80
3.3.3.4	Renaming actions	81
3.3.3.5	Running actions	81
3.3.3.6	Saving Script	82
3.3.3.7	Opening Script	82
3.4	Functions	83
3.4.1	MFG (Manufacturing)	83
3.4.1.1	Test concept	83
3.4.1.2	Protocol Parameters	84
3.4.1.3	RF Parameters	87
3.4.1.4	Getting the result	88
3.4.2	NST SG (Signal Generator)	89
3.4.2.1	Protocol Parameters	90
3.4.2.2	RF Parameters	92
3.4.3	NST SA (Signal Analyzer)	92
3.4.3.1	Protocol Parameters	93
3.4.3.2	RF Parameters	95
3.4.4	FUOTA Test	95
3.4.4.1	Test concept	95
3.4.4.2	Fragmentation Parameters	96
3.4.4.3	Multicast Parameters	97
3.4.4.4	Test Procedures	97
IV.	Report Functions	99
4.1	Report File Manager	100
4.1.1	Creating Report	100
4.1.2	How to Open the Saved Report File	101

I. Getting Started

This chapter explains how to download and start the RWC5020x/5021x application program.

- 1.1 Download and Installation
- 1.2 Starting the Application
- 1.3 GUI Structure

1.1 Download and Installation

RWC5020x/5021x application program is provided through email or download link and the downloaded file can be unzipped into users' directory. The following figures show an example.




Fig 1.1 Downloading Zip file from the RedwoodComm website

Unzip the zip file and install the executable file as the install wizard guides. It is a 32bits application program and will be installed C:\Program Files (x86)\RWC\RWC5020x. It may be installed in other directories as users like as well.




Fig 1.2 Installation wizard

After installation, you can see directories and files as follows (Figure 1.3)




Fig 1.3 Installed directory structure

In directory RWC502x /

Executable file RWC502x_App.exe

Dll files

DEMO directory

Manual directory

In directory DEMO /

An example demo project data: DEMO_Vxxx0.prj and the same named directory

In directory DEMO_V1330/

Example DUTs : dut_name.ini and the same named directories

In directory manual

RWC502x LoRaWAN Tester Application Program manual (V1.xxx).pdf

RWC502x LoRaWAN Tester User Manual (Ver 1.xxx ENG).pdf

RWC502x PC APP Release Note.pdf

RWC502x Firmware Release Note.pdf

Note: PC's OS

1. Windows is supported, but Linux and IOS are not supported.
2. Users are recommended to use windows7 or later versions as OS.
3. If you want to avoid the authorization problem with your OS system, please install this application on a non-system disk, such as 'D drive'.

Language setup

1. Users are strongly recommended to use '' than ',' for decimal symbols.
 2. Users are strongly recommended to use ',' than '.' for digit grouping symbols.
 3. Users are strongly recommended to use English over other languages.
-

1.2 Starting the Application

When you execute the application 'RWC502x_App.exe', it will start as shown in the figure 1.4.




Fig 1.4 Initial screen of the application

1.2.1 Connection

Users need to make a connection between this application and the RWC5020x/5021x equipment. Connection means that the application recognizes if a correct equipment is connected, if it has validated licenses, and so on. After connection, the application shows the type of recognized equipment, the serial number, version of Firmware, and makes functions enabled according to the type of equipment and licenses.



Fig 1.5 Title message of RWC502x application

In order to connect the application to RWC5020x/5021x, click on [SETUP/Connect RWC502x] menu or  icon. This will bring up the pop-up window.




Fig 1.6 RWC502x CONTROL PORT WINDOW

There are two connection methods, LAN or COM. The connection via LAN means that the application controls equipment via wired LAN or WIFI. The connection via COM means that the application controls equipment via UART(RS232, VCOM). For safe connection, it is recommended to connect a PC to RWC 502x by a wired LAN method. For more detailed description, please refer to chapter 2.3.

1.2.2 Identification of RWC5020x/5021x

There are a couple of types of equipment operated with this RWC5020x/5021x application program, such as RWC5020A, RWC5020B, RWC5020M, and RWC5021P.

This application program detects the type of equipment automatically and limits some functions according to the equipment.

RWC5020A(Discontinued for sales) : Stand-alone type equipment

RWC5020B : Stand-alone type equipment. It has frequency measurement function and more accurate performance than RWC5020A.

RWC5020M : Dongle type equipment. It has the same functions and performance accuracy as the RWC5020B.

RWC5021P : Dongle type protocol tester. It has limited functions such as pre-certification test, and link analyzer compared to the others.



Fig 1.7 RWC5020x/5021x equipment series

1.3 GUI Structure

RWC5020x/5021x application program consists of three classified functional windows: Project menu windows, Test functions windows, and Report functions windows. In the following figure, the functions in the blue-colored box are project menu windows, and the windows in the red-colored box are test related ones, and the windows in the green-colored box are report related ones. The next chapters will include the detailed explanation about each window respectively.





Fig 1.8 Function window classification

This application consists of 4 classified functions such as LoRaWAN® pre-certification test, performance test, Link analyzer, and functionalities (Fig 1.9). Clicking the one of the main menu buttons changes the test function window and report function window (Fig 1.10).




Fig 1.9 Main menu buttons

1.3.1 Test function windows



a. Pre-Certification Test Window

b. Performance Test Window



c. Link Analyzer Window

d. Functionality Test Window

Fig 1.10 Test function windows

1.3.2 Report function windows

The report function windows have different functions from the test functions. If you click on one of the main menu buttons, the test function window will appear on the left side and report function window will appear on the right side (figure 1.11).

CREATE REPORT OPEN REPORT

TIME Elapsed Estimated
Total 00:00:00 00:00:00
Curr-Item 00:00:00 00:00:00

LORA CERTIFICATION TEST SUMMARY (EU V1.6)

ITEMS	VERDICT	SUB VERDICT
1 Activation and Deactivation Pre and Post test	PASS	
1.1 Certification Application Activation		PASS
1.2 Certification Application Deactivation		PASS
2 Over the Air Activatin	PASS	
2.1 Pre-Join Behaviour		PASS
2.2 Join Accept with DLSettings		PASS
2.3 Join Accept with Delay Settings on RX2 window		PASS
2.4 Join Accept with CFList		PASS
2.5 DevNonce Verification for Join Request		PASS
3 Activation by Personalization	PASS	
3.1 Activation by Personalization		PASS
4 Certification Application Functionality	PASS	
4.1 Default Setting Test		PASS
4.1.a Channel Plan and Usage		PASS
4.1.b Cryptograph		PASS
4.1.b.i AES Encryption		PASS
4.1.b.ii Message Integrity Code		PASS
4.1.c Downlink Error Rate		PASS
4.1.d Receive Window Timing		PASS
4.1.e Frame Sequence Number		PASS
4.1.e.i Uplink Sequence Number		PASS
4.1.e.ii Downlink Sequence Number		PASS
4.1.e.iii Downlink Sequence Number Rollover		PASS
4.2 Confirmed Frames		PASS
4.2.a Confirmed Uplinks		PASS
4.2.b Confirmed Uplink Retransmission		PASS

View SPY MSG (Max. 300 Lines) 1.0 CLEAR MSG [TEST TIME] Begin : Finish :

DUT PORT RxBGAIN LOW

a. Pre-Certification Report Window

CREATE REPORT OPEN REPORT

TIME Elapsed
Total 00:19:37
Curr-Item 00:00:00

SENSITIVITY TEST

PERFORMANCE TEST SUMMARY

DUT NAME EDY_PERF_EU868
REGION EU_868

PER USING RX1 WINDOW : PASS

DR	Start	Step	Stop	Target	#Pkt	Criteria	Result	Verdict
DR0	-129.0	1.0	-138.0	0.100	1	-133	-136.0/0.000	PASS
DR1	-126.0	1.0	-135.0	0.100	1	-130	-134.0/0.000	PASS
DR2	-125.0	1.0	-134.0	0.100	1	-129	-132.0/0.000	PASS
DR3	-122.0	1.0	-131.0	0.100	1	-126	-128.0/0.000	PASS
DR4	-119.0	1.0	-128.0	0.100	1	-123	-124.0/0.000	PASS

SCALE 1.0 CLEAR MSG

SPY MESSAGE CLEAR SAVE

View SPY MSG (Max. 300 Lines) [TEST TIME] Begin : Finish :

DUT PORT Control DUT while test RxBGAIN LOW

b. Performance Report Window

Fig 1.11 Report function windows

II. Menus

This chapter explains how to handle a project, DUT, test condition and test environment. With the project menus, users can create, open a project file, delete the currently opened project, and create or delete DUT files. Users can also open the ready-made demo project.

2.1 PROJECT

2.2 SETUP

2.3 UTILITY

2.4 ABOUT

2.1 PROJECT

2.1.1 Project Menu

With the project menus, users can create a new project file, open an existing project file, or delete the currently opened project. Users can also open the ready-made demo project. The [PROJECT] menu consists of three sub-menus: [New Project], [Open Project] and [Del Current Project].




Fig 2.1 Project Menu

2.1.1.1 New Project

To start any test, at least two basic works must be done; one is creating a project and the other is creating a DUT. When you create a new project, 'project_name.ini' file and the same named directory will be created. A project must have at least one DUT. A project may have many DUTs. When a project is created, the project name and directory information will be displayed in the project information windows.




Fig 2.2 Project Menu and sub menus




Fig 2.3 Creating a project window



Fig 2.4 Example of a new project (DUT empty)

2.1.1.2 Opening Project

Using the [Open project] menu, users can open one of the existing projects that were created by this application. When a project is opened, the last tested DUT file will also be opened automatically.

2.1.1.3 Deleting Current Project

Using the [Del Current Project] menu, you can delete the currently opened project including all DUT files in the project folder. All deleted projects or DUT files cannot be recovered. Be careful when deleting projects or DUTs. To prevent unwanted deletion, only the opened project can be deleted.

2.1.1.4 Project List

Project List menu shows the list of projects in the current directory. Just clicking one of the listed projects will open the project. Maximum of 7 project names will be saved.




Fig 2.5 Project List Menu

2.1.1.5 Opening Demo Project

[Open Demo Project] opens the ready-made demo project.

The demo project is installed with the installation of the RWC5020x/5021x application in '.\DEMO\', the sub-directory of the application installation directory.




Fig 2.6 [Open Demo Project] menu and directory information

2.1.2 DUT menu

In this application, DUT means 'device name to be tested'. DUT is a member of a project. Before creating a new DUT, a project must be created or opened. If a project is created or opened, as many DUTs can be created in the project as users need. When a new DUT is created, a 'DUT_name.ini' file and the same named directory will be created.

2.1.2.1 New DUT

Clicking on the [New DUT] menu in the DUT Menu or NEW button brings the 'NEW DUT CREATION' popup window, which is designed to help you create a new DUT. Type a DUT name, select one of DUT types, select one of regions, and click the [CREATE] button.




Fig 2.7 New DUT Menu

Before DUT file is created, users must select some parameters related to LoRaWAN protocols such as DUT type, region, LoRaWAN® version, Class, Operator(KR, CN), channel mode(AS), channel plan(CN) and Frequency offset(AS region) shown in the figure 2.8 as they want to test. Once a DUT file is created, the name of the DUT, and the parameters mentioned above cannot be modified.If you want to modify any of them, you must create a new one. The AUTO NAMING will help you quickly name it.




Fig 2.8 Creating a new DUT

The list of DUT names that you created will be shown in the DUT list box as shown in the following figure.




Fig 2.9 List of DUT names

2.1.2.2 DEL Current DUT

Using [DEL Current DUT], you can delete the currently opened DUT file. Be careful when deleting DUTs because the deleted DUT file cannot be recovered. To prevent unwanted deletion, only the opened DUT can be deleted in this application.




Fig 2.10 Del Current DUT menu

2.2 SETUP

2.2.1 Connect RWC5020x/5021x

RWC5020x/5021x Application works under connection between users' PC and RWC5020x/5021x.




Fig 2.11 Connect RWC502x menu

2.2.1.1 Open RWC5020x/5021x CONTROL PORT window

Clicking on [Connect RWC502x] in SETUP Menu or clicking on  icon will show the 'RWC502x CONTROL PORT' window which is designed to help you set up RWC5020x/5021x's IP. There are two ways to connect your PC and RWC5020x/5021x equipment via LAN and COM(RS232).

2.2.1.2 Connection via LAN

Set the IP address same as the RWC5020x/5021x's IP address connected to the PC and click the [CONNECT] button. If your PC recognizes an RWC5020x/5021x, the status [CONNECT] will be changed to [CONNECTED]. After connection, the application's title bar will show the version, equipment types (RWC5020A/B/M), and local PC's network IP. Some of the functionality or parameters will be limited according to the type of RWC5020x/5021x.

The PC's IP information is useful to set up the server information when you test Gateway's Non-regression performance.



Fig 2.12 Make a connection between PC and RWC5020x/5021x via LAN

RedwoodComm : LoRaWAN Autotest(Version : 1.327 RWC5021P)


a. Information on the application title bar(SW version & equipment type)




b. information of the FW(equipment type, version, serial number)

Fig 2.13 The information after connection with an RWC5020x,5021x equipment

In order to scan the IP that is connected with RWC502x equipment, click the [SCAN] button. It will scan all IPs by changing only the last IP addresses 1 upto 254 with “*IDN?” command. The first three addresses of the search target are the same as the IP address of the user-editable address. The result will be display win the SPY message window.



a. Scan IP function




b. Result information

Fig 2.14 The scan function to find the IP connected with 502x equipment

2.2.1.3 Connection via COM Port

Set the IP address same as the RWC5020x/5021x’s IP address connected to the PC and click the [CONNECT] button. If the application recognizes an RWC5020x/5021x, the status [CONNECT] will be changed to [CONNECTED].

After connection, all information will be displayed the same as the LAN connection case.




a. Before connection

b. After connection

Fig 2.15 Make a connection between PC and RWC5020x/5021x via COM

If RWC5020x/5021x is connected via COM, changing the address and type of IP is allowed. Users can get the current address and type of IP of RWC5020x/5021x by clicking the [GET] button. Users can set the address and type of IP as you want by clicking the [SET] button. Changing IP address is only available in STATIC mode.



a. Changing IP is allowed with STATIC mode

b. Changing IP is not allowed with DYNAMIC mode

Fig 2.16 Control window to change the address and type of IP.




Fig 2.17 The information after connection with an RWC5020x,5021x equipment via COM

2.2.2 Control DUT (ED)

This function is used to control DUT via RS232 while testing as needed.

Control DUT menu consists of five sub menus: Open Port, Load User Cmds, Show User Cmds, Pop DUT Monitor, and Make Cmds Template. This function will be enabled in the SKT certification test.





Fig 2.18 Control DUT Menu

2.2.2.1 Open PORT

Clicking [Open PORT] will show a 'DUT CONTROL PORT' window that is designed to help set and open UART port for DUT control. After configuring its port number and baud rate, click the [OPEN PORT] button within the DUT Control Port window. If there is a valid RS232 port, [OPEN PORT] text will be changed to [CLOSE PORT] and 'PORT No.' and 'BAUD RATE' combo boxes will be disabled. If there are no items in the 'PORT No.' combo box, click on the [RESCAN] button.



a. Before opening port

b. After opening port

Fig 2.19 DUT Control Port Setup

2.2.2.2 Load User Commands

Clicking [Load User Cnds] will show 'Open File Window' for opening a DUT control file (.txt) which describes configuration and user commands. If you want to create your own command file, use the [Make Cnds Template] function which helps you create a template file.

2.2.2.3 Show User Commands

Clicking [Show User Cnds] will show the 'USER COMMAND MAPPER' window and show user-defined commands which are loaded in 2.2.2.2. If it is needed to create a new user command file, click on the [TEMPLATE] button to open a template and create a new one.




Fig 2.20 Example of USER COMMAND MAPPER

2.2.2.4 Show DUT Monitor

Clicking [Show DUT Monitor] will show a pop-up window to show the commands and DUT’s responses.





Fig 2.21 DUT Monitor screen

2.2.2.5 Make Commands Template

Clicking [Make Cmds Template] will create a template file that is designed to help create users’ own control commands file. You can fill it up and save it as a text file (.txt) and load it onto ‘USER COMMAND MAPPER’ using the [Load User Cmds] menu.



```
USER_CTRL_CMD_TEMPLATE.INI - Notepad
File Edit Format View Help
[CONFIG]
VENDOR=NONAME
NUM_CMDS=34
BAUDRATE=115200
EOL=rn
SEQ_CMD_INTV=1.5
[CMDS]
set_class_a=NONE; //insert your command and parameter
set_class_b=NONE;
set_class_c=NONE;
set_ul_cycle_off=NONE;
set_ul_cycle_on=NONE;
set_activation=NONE;
set_app_key=NONE;
set_dev_eui=NONE;
set_app_eui=NONE;
set_apps_key=NONE;
set_nwks_key=NONE;
set_dev_addr=NONE;
reset_device=NONE;
do_pseudo_join=NONE;
set_adr_en=NONE;
set_adr_dis=NONE;
set_dr0=NONE;
set_dr1=NONE;
set_dr2=NONE;
set_dr3=NONE;
set_dr4=NONE;
set_dr5=NONE;
set_rtr_num=NONE;
send_data_cfm=NONE;
send_data_uncfm=NONE;
```

Fig 2.22 Template file to help to create a your command file

2.2.3 Control DUT (GW)

This application provides a simple server function for Gateway’s non-regression test defined by SEMTECH.

In order to communicate with DUT(Gateway) in JSON, users have to set the gateway’s IP and server’s port number.

[Control DUT(GW)/Config IP] menu or [GW IP] button on NON-REGRESS tab of PERFORMANCE function tap shows

‘GW IP/HOST PORT’ window which will help you set the gateway’s IP and the HOST(Server)’s port number.



Fig 2.23 [Control DUT(GW)/Config IP] menu




Fig 2.24 [GW IP/HOST PORT] menu

A selected IP address of the PC will be displayed as a SERVER IP at the bottom of the setup window.(ex. SERVER IP:192.168.0.10). Users must set the server IP same to the above SERVER IP in the setup file of Gateway. If all parameters are set up correctly, the RWC5020x/5021x application will start to wait for gateways messages. After receiving a JSON packet, this application will respond to the gateway as a server. All IP addresses and sockets of the user PC will be listed up. Users may select one of the lists.

2.2.4 Parameter Configuration

[Parameter Config] or shows a window in which users can set up the basic properties of DUT. This configuration is applied to all test functions of the application.




Fig 2.25 Parameter Config menu for displaying 'Parameter configuration' window

When you open the parameter configuration window without connection with the RWC5020x/5021x, a warning message box will appear to remind that all changed parameters will be adopted only after connection.




Fig 2.26 Warning no connection




Fig 2.27 PARAMETER CONFIGURATION

2.2.4.1 Protocol Parameters

All parameters are defined in LoRaWAN® Alliance’s specification. Some of the parameters will be changed according to the DUT type, region, LoRaWAN® version, activation method, and class.

TestMode @Activation

This parameter determines whether to force DUT to enter certification test mode by sending the Activated Test Mode command after the activation procedure. For LoRaWAN1.0.4 and LoRaWAN1.1, the TxPerChangeReq MAC command is used instead of the Activated Test Mode command. It will be shown in Link analyzer mode of EDT.

Check_EUI

This parameter decides whether or not to compare DEV_EUI and APP_EUI during activation. If this parameter is checked, RWC5020x/5021x (Gateway/Server) compares DEV_EUI and APP_EUI and accepts only if the value is equal to the same.

DUT_TYPE

There are two types of DUT, END DEVICE and GATEWAY. If the DUT type is END DEVICE, RWC5020x/5021x operates as a gateway. If the DUT type is GATEWAY, it operates as an end device.

REGION

RWC5020x/5021x supports various regions [EU 868, EU 433, US 915, AU 915, CN 470, KR 920, AS 923, IN 865, RU 864, KZ 865, IL 917]. Using this parameter, users could select the region to test.

OPERATOR

This parameter determines whether to enable LoRa operator-specific procedures and parameters. It is only applicable to South Korea (SKT) and China (ICA) in the current version of firmware.

PROTOCOL_VER

This parameter defines the version of LoRaWAN® protocol to be emulated by RWC5020x/5021x.

Supporting versions: 1.0.2 / 1.0.3 / 1.0.4 / 1.1

CLASS

There are three different classes in LoRa devices. Class A is Bi-directional End Devices, Class B is Bi-directional End Devices with scheduled receive slots, and Class C is Bi-directional End Devices with maximal receive slots. This parameter defines the class mode of RWC5020x/5021x.

ACTIVATION

LoRaWAN® defines two types of Activation procedures (OTAA, ABP). This parameter defines the activation mode of RWC5020x/5021x.

APP_KEY

The APP_KEY is an AES-128 root key specific to the End Device. Whenever an End Device joins a network via over-the-air activation, the APP_KEY is used to derive the session keys NwkSKey and AppSKey specific for that End Device to encrypt and verify network communication and application data. This parameter must be set to the same value as the APP_KEY on DUT.

DEV_EUI

The DEV_EUI is a globally unique End Device identifier. The DEV_EUI is stored in the End Device before the activation procedure is executed. If the CHECK_EUI is ON, this parameter must be set as the same value stored on the DUT.

APP_EUI

The APP_EUI is a global application ID in IEEE EUI64 address space that uniquely identifies the entity able to process the Join-request frame. The APP_EUI is stored in the End Device before the activation procedure is executed. If the CHECK_EUI is ON, this parameter must be set as the same value stored on the DUT.

DEV_ADDR

During the activation, the gateway assigns DEV_ADDR value to the End Device. If activation mode is ABP, this parameter must be set as the same value stored on the DUT. If activation mode is OTAA, this parameter value is used to generate a Join-accept message.

APPS_KEY

APPS_KEY is used to encrypt and verify application data between Gateway and End Device. This value is derived from APP_KEY during OTAA. If activation mode is ABP, this parameter must be set as the same value stored on the DUT.

NWKS_KEY

NWKS_KEY is used to encrypt and verify network data between Gateway and End Device. This value is derived from APP_KEY during OTAA. If activation mode is ABP, this parameter must be set as the same value stored on the DUT.

UPDATE_FCNT

This parameter determines the initial value of FCNT before activation procedure and also updates FCNT values after activation.

ADR

LoRa network allows the End Devices to individually use any of the possible data rates. This feature is used by the LoRaWAN® to adapt and optimize the data rate of static End Devices. This is referred to as Adaptive Data Rate (ADR) and when this is enabled the network will be optimized to use the fastest data rate possible.

DOWNLINK_SLOT

When RWC5020x/5021x emulates Gateway/Server mode (EDT), it could respond to the uplink frame by downlink frame using RX1 window or RX2 window. Using this parameter, users can select the RX window for testing the DUT.

NET_ID

The NET_ID is a network identifier to uniquely identify the network. This parameter value is used to generate a Join-accept message.

RX1_DR_OFFSET

This parameter sets the offset between the uplink data rate and the downlink data rate used to communicate with the End Device on the first reception slot (RX1). This parameter value is used to generate a Join-accept message.

RX2_DR

This parameter defines the data rate of a downlink using the second receive window. This parameter value is used to generate a Join-accept message.

RECEIVE_DELAY

The first receive window RX1 opens RECEIVE_DELAY seconds after the end of the uplink modulation. This parameter value is used to generate a Join-accept message.

LINK_MARGIN

This parameter is an 8-bit unsigned integer in the range of 0~254 indicating the link margin in dB of the last successfully received *LinkCheckReq* command. This parameter value is used to generate *LinkCheckAns* command.

GATEWAY_CNT

This parameter is the number of gateways that successfully received the last *LinkCheckReq*. This parameter value is used to generate *LinkCheckAns* command.

YEAR

This parameter indicates the year of RWC5020x/5021x time information. This parameter is used to generate *DeviceTimeAns* command and Beacon.

MONTH

This parameter indicates the month of RWC5020x/5021x time information. This parameter is used to generate *DeviceTimeAns* command and Beacon.

DAY

This parameter indicates the day of RWC5020x/5021x time information. This parameter is used to generate *DeviceTimeAns* command and Beacon.

HOUR

This parameter indicates the hour of RWC5020x/5021x time information. This parameter is used to generate *DeviceTimeAns* command and Beacon.

MINUTE

This parameter indicates the minute of RWC5020x/5021x time information. This parameter is used to generate *DeviceTimeAns* command and Beacon.

SECOND

This parameter indicates the second of RWC5020x/5021x time information. This parameter is used to generate *DeviceTimeAns* command and Beacon.

NETWORK

This parameter indicates the type of LoRa network, in other words the synchronization word to be used in LoRa modulation.

2.2.4.2 RF Parameters

RF parameters are related with RWC5020x/5021x's hardware, test environment, and control parameters.

TX POW

This parameter defines the output power of RWC5020x/5021x in dBm.

INIT_RX_GAIN

The RWC5020x/5021x has an AGC (Automatic Gain Control) function. So the RWC5020x/5021x will set appropriate RX gain after receiving a few packets from the DUT. This parameter defines the initial RX gain when the Link is started. It is very important to set this parameter correctly to get the proper test result quickly. Set to LOW if the expected input level from your DUT to RWC5020x/5021x is higher than -15dBm. Set to HIGH if the expected input level is lower than -40dBm. Otherwise set it to MIDDLE.

PATH_LOSS

Users can set the path loss between the RF port of RWC5020x/5021x and DUT RF port. RWC5020x/5021x's real output power will be increased by this value to compensate for path loss.

SYSCLK_OFFSET

This parameter defines the system clock frequency (32MHz) offset value in ppm. It modifies RF frequency as well as LoRa modulation signal.

FREQ_OFFSET

This parameter defines the RF frequency offset value in ppm.

TIME_OFFSET

This parameter defines the time offset value in us.

CH_MASK_0

This parameter defines the mask of channels to be used for LoRa communication, which is applicable only to regions of EU 868, EU 433, KR 920, AS 923, IN 865, RU 865, and KZ 865.

CH_GROUP

This parameter defines the mask of the channels to be used for LoRa communication, which is applicable only to regions of US 915, AU 915, and CN 470.

RX2_FREQ

This parameter defines the frequency of a downlink using the second receive window.

RX2_DR

This parameter defines the data rate of a downlink using the second receive window.

DL_CH_00 ~ DL_CH_07

This parameter defines the real channel frequency of each downlink channel index.

UL_CH_00 ~ UL_CH_07

This parameter defines the real channel frequency of each uplink channel index.

UL_CH_64 ~ UL_CH_71

This parameter defines the real channel frequency of each 500kHz uplink channel index.

2.2.5 Remote by Other host

This application provides a way to control itself by other controllers via RS232. This function is a quite limited way to control but is useful to test pre-certification remotely. For more detail, refer to the application note.




Fig 2.28 [Config Remote Port] menu




Fig 2.29 REMOTE CONTROL setup window

To see the remote commands, click on the [Show Cmd List] menu.



Fig 2.30 [Show Comd List] menu

REMOTE COMMANDS LIST	
PC:CONF:MODE [PARAM]	PARAM=CERT/PERF/UTIL/LINK
PC:CONF:CERT:EU_CERT [PARAM]	PARAM=SEL_ALL/DESEL_ALL
PC:CONF:CERT:US_CERT [PARAM]	PARAM=SEL_ALL/DESEL_ALL
PC:CONF:CERT:AS_CERT [PARAM]	PARAM=SEL_ALL/DESEL_ALL
PC:CONF:CERT:KR_CERT [PARAM]	PARAM=SEL_ALL/DESEL_ALL
PC:CONF:CERT:IN_CERT [PARAM]	PARAM=SEL_ALL/DESEL_ALL
PC:CONF:CERT:REGION [PARAM]	PARAM=EU/US/AS/KR/IN
PC:READ:IDN?	
PC:READ:RWC5020X_SERIAL?	
PC:READ:COMMANDS?	
PC:READ:CERT_STAT?	
PC:READ:CERT_CURR?	
PC:EXEC:CREATE_DUT [PARAM]	PARAM=DUT_NAME(just)
PC:EXEC:OPEN_DUT [PARAM]	PARAM=DUT_NAME(just)
PC:EXEC:CREATE_PRJ [PARAM]	PARAM=PRJ_NAME(should be full path including drive name)
PC:EXEC:CERT START	
PC:EXEC:CERT STOP	
PC:EXEC:CON_RWC5020 [PARAM]	PARAM=123.123.123.123

Fig 2.31 Remote commands list for controlling PC application program

2.2.6 Utility Environment

This function is for user convenience. All options are saved and reloaded automatically

DUT CONTROL ENVIRONMENT

- Load commands at start

This application remembers the last user command file name. If you check this option, it will load the last user command files when the application is started.

- Open port at start

This application remembers the last opened RS232 port name. If you check this option, it will reconnect the last opened RS232 port when started. But be careful when using this option, because it could take longer to launch the application if there is no same port anymore.




Fig 2.32 [Utility Environment] menu

REPORTING OPTION

- Open report after creation

If you check this option, the application will open the created report automatically when you create a report file. If not checked, the report will be created but not opened automatically.

APPLICATION ENVIRONMENT

- NO asking when naming

If you check this option, the application will create or save files without opening a file wizard window.

- Load last project at start

If you check this option, the application will open the last opened project when it starts.

- Show local IP on app.

If you check this option, the application will show your PC’s IP address on the top.

- Initialize All Parameters with new DUT.

If you check this option, this application will initialize all test parameters as default without asking. If not checked, it will use them as it was.

MESSAGE MAXIMUM LINE NUMBER

- o LINK ANALYZER

The maximum line number of the log window in the Link analyzer tab.

Range : 100 - 3000

- NRT JSON

The maximum line number of the JSON log window in the non-regression test function tab.

Range : 100 - 3000

- SPY MSG

The maximum line number of the SPY message window

Range : 100 - 1000

THEME

- BLUE

This option sets the color theme of the application as blue.




Fig 2.33 Blue theme of RWC5020x/5021x application

- GRAY

This option sets the color theme of the application as gray.




Fig 2.34 Gray theme of RWC5020x/5021x application

○ GREEN

This option sets the color theme of the application as green.




Fig 2.35 Green theme of RWC5020x/5021x application

2.3 UTILITY

It consists of 3 utility functions: DUT Control, Tester(RWC5020x/5021x) Control, and Screen capture. You can find them on the UTILITY menu tab at the top of the application. Screen Capture function will be enabled when it is available according to the type of equipment.




Fig 2.36 Utility menus

2.3.1 DUT Control




Fig 2.37 DUT control menu

This function is a simple terminal tool. It helps users control DUTs through RS232 using string command. Users can transmit DUT control commands all by one click or line-by-line.

2.3.1.1 How to Use

You can type your own remote control commands and click  then it will transmit commands to RWC5020x/5021x sequentially. Users can use a special command SLEEP which lets the PC wait for transmitting for the specified duration of time. The parameter of SLEEP is time in millisecond units, e.g., SLEEP 1000 makes PC wait for 1000ms.




Fig 2.38 Sending commands of DUT Control function

2.3.1.2 Verify Commands

Clicking **VERIFY** will verify the commands on the editor. Verifying criteria is based on the loaded user commands. Verified commands will be colored. The blue colored commands are user commands, and the grey colored ones are not user commands.

2.3.1.3 Transmission Methods

Clicking **RUN** will start transmitting commands. Transmitting commands will be stopped when you click **Stop** or once all commands are transmitted. Clicking **SEND CMD** will transmit the selected command. Clicking **LINE BY LINE** will transmit listed commands line by line.

2.3.2 RWC5020x/5021x Control




Fig 2.39 RWC5020x/5021x control menu

This function is a simple terminal tool. It helps users control RWC5020x/5021x through LAN using string commands. Users can transmit RWC5020x/5021x remote commands all by one click or line-by-line.

2.3.2.1 How to Use

Clicking  will start transmitting commands on the command window sequentially. Users can use a special command SLEEP, which will make the PC wait until the next command transmission is ordered. The parameter of SLEEP is time in millisecond units, e.g., SLEEP 1000 makes the PC wait for 1000ms.

2.3.2.2 Template

Template functions will fill the commands window with ready-made commands sequence as an example.




Fig 2.40 Sending commands of RWC5020x/5021x Control window

2.3.2.3 Sending commands

Clicking  will start transmitting commands. Transmitting commands will be stopped if you click  or once all commands are transmitted. Clicking  will transmit the selected command. Clicking  will transmit the listed commands line by line increasing the command number.

2.3.3 Screen Capture




Fig 2.41 Screen capture menu

Clicking  will capture and show the current screen of the connected RWC5020x/5021x and save it as a bmp file. If you click one of the listed-up files on the list window, the selected bmp file will be shown on the image window. It will be enabled with RWC5020A and B but not with RWC5020M.




Fig 2.42 Screenshot of the RWC5020A/B

2.4 ABOUT

It is not functional but informational menus. It consists of 5 menus : Manual, Upgrade Notice, Licenses, About application, and Website .




Fig 2.43 About menus

2.4.1 Manual

Clicking [Manual] will show the operation manual of this application. Clicking the name of each manual will open the Redwoodcomm's website to let users download the latest version of manuals.



Fig 2.44 Opening the manual

RWC5020x Application Program Manual : The PC application operation manual

RWC5020x Tester User Manual : The stand-alone equipment user manual including remote control commands

PC APP Release Note : Release note for pc application release

Firmware Release Note : Release note for firmware release

2.4.2 Upgrade Notice

Users can check the latest version of this application software using the [Upgrade Notice] menu.




Fig 2.45 Upgrade Notice menu and information window

Clicking on [OPEN SITE] button will open up the download web page of RedwoodComm.




Fig 2.46 Download page of RedwoodComm web page

2.4.3 Licenses

After connecting the application to RWC5020x/5021x, users can see the included licenses by clicking on the Licenses menu. Available regional licenses can be different according to the version of software, policy of sales, or LoRaWAN version. If you want to add options, please contact to sales@redwoodcomm.com.




Fig 2.47 An example of included licenses in the RWC5020x

2.4.4 About Application

This function shows the SW version and Image of which is connected equipment



Fig 2.48 About image of RWC5020x/5021x

2.4.5 Website

This function launches a web browser and opens the RedwoodComm's website <https://Redwoodcomm.com> automatically.

III. Test Functions

This chapter explains how to use pre-certification tests, RF performance tests, Link Analyzer, other functions and utilities. With test functions, you can select one of the tests, handle test operation, and set up a test environment.

- 3.1 Pre-Certification Test
- 3.2 Performance Test
- 3.3 Link Analyzer
- 3.4 Functions

3.1 Pre-Certification Test

This application provides the LoRaWAN® pre-certification test functions. Refer to the fig 3.1 for simple operation of the function. It has 4 test condition add raw data, stop link after test, test ADR, test Opt DR.

- Add raw data** : Test option for adding raw data or not in test test result
- Stop link after test** : Test option for sending “EXEC:LINK:STOP” command to break join after pre-certification Test. By unchecking the option, there is no need to reset the DUT when users do the pre-certification test again.
- Test ADR** : Option for enabling test items related with ADR
- Test Opt DR** : Option for enabling test items related to optional DR in every region.





Fig 3.1 Test function window for LoRaWAN® pre-certification.

3.1.1 LoRaWAN® Pre-Certification

This application provides a test function which is compatible with the LoRaWAN® protocol test. We named it LoRaWAN® Pre-certification. It is available in the version of ‘1.0.2/1.0.3’ and ‘1.0.4’. For the version ‘1.0.2/1.0.3’ it

provides 5 regions such as EU, US/CA, AS, KR, and IN. For the version '1.0.4' it provides 9 regional pre-certification tests such as EU868, EU433, US/CA, AS, KR, IN, RU, AU, and IL. Other regional certification functions will be added as soon as they are published. If you select the region and version of LoRaWAN® when you create a new DUT file, all regional parameters and test items will be configured automatically according to the certification.



a. LoRaWAN® Version 1.0.2/1.0.3

b. LoRaWAN® Version 1.0.4

Fig 3.2 Two different pre-certification test a.to the versions of LoRaWAN® (EU case)

3.1.2 Operator Certification

There is an Operator Certification option, SKT. Other private certifications could be added according to further requests.




Fig 3.3 A special operator's certification test (SKT)

3.1.3 Pre-Certification Test Items

3.1.3.1 Meaning of Text Colors

Each color has the meaning of verdict; the blue-colored items mean PASSED, the red-colored items mean FAILED, the black-colored items mean NOT_TESTED, and the grey-colored ones mean Not-selected OPTIONAL items.




Fig 3.4 Colored text in pre-certification test window

3.1.3.2 Selection and Test Parameter Configuration

Select the test items to be tested by clicking the check boxes in front of the subtitles. If you click a test item, its test parameters will be shown at the bottom of test items.





Fig 3.5 Configuration of Test Parameters

3.1.3.3 Start Test

If you click  button, all selected items will be tested sequentially. Keep in mind the RWC5020x/5021x application program will automatically overwrite the result after each item is tested without asking whether the selected item was tested previously or not. In other words, the application will always keep the recent test results.

3.1.3.4 Control DUT

If you want to control DUT while testing, have the box **Control DUT** checked. Then this application will send control commands according to the loaded user control command file. Refer to 2.2.2 for DUT control. You can see the transmitted commands and received responses to/from DUT respectively on the DUT control monitor window. Click the  button and a large DUT control monitor will pop up.




Fig 3.6 DUT Control Monitor

COM PORT and BAUD RATE information of the current control port will be displayed as follows.



a. Before connection b. After connection

Fig 3.7 COM PORT and BAUD RATE after connection.

3.1.3.5 Test Result – Summary Table

If you click on the certification title, you can see the test summary table on the result window.





Fig 3.8 Displaying Test Result – Summary Table

3.2 Performance Test

Performance test function consists of PER & POWER, LBT, and NON-REGRESS test. Refer to the figure 3.10 for an example. It has a “ Stop link after test” option.

- Stop link after test** : Test option for sending “EXEC:LINK:STOP” command to break join after performance test. By unchecking the option, there is no need to reset the DUT when users do the performance test again.



The screenshot shows the 'PERFORMANCE' configuration window. On the left, there are buttons for 'PER & POWER', 'LBT', and 'NON-REGRESS'. The 'PER & POWER' section is active. Below these are 'Buttons for selection test category' and a 'Test condition for performance test' checkbox. The main area is divided into 'SENSITIVITY AND TX POWER - TABLE' and 'TEST CONDITIONS'. The 'TEST CONDITIONS' section includes a 'Test condition box' with a 'SYNC RX1/RX2' checkbox, 'TEST PARAMETERS' for DR0-DR7, and 'OPTION' checkboxes for 'SHOW GRAPH' and 'SHOW LINK MESSAGE DURING TESTING'. Annotations on the right side point to the 'SYNC RX1/RX2' checkbox and the 'TEST PARAMETERS' table.

DR	START	STOP	CRITERIA
DR0	-100.0	-150.0	-100.0
DR1	-100.0	-150.0	-100.0
DR2	-100.0	-150.0	-100.0
DR3	-100.0	-150.0	-100.0
DR4	-100.0	-150.0	-100.0
DR5	-100.0	-150.0	-100.0
DR6	-100.0	-150.0	-100.0
DR7	-100.0	-150.0	-100.0

Fig 3.10 Test parameters and conditions

3.2.1 PER & POWER

This function allows RWC5020x/5021x to search the sensitivity level by measuring the PER (Packet Error Rate) and measure TX power of DUT according to the test parameters and conditions. You can modify test conditions and parameters. If you click on the [CONFIG] menu, you can set protocol parameters in the PARAMETER CONFIGURATION window.

3.2.1.1 Selection item

Select or deselect each item that you want to test by clicking each checkbox in the test items box. If you want to add or remove all test items at once, have the check box of the title checked or unchecked in the test function box. Whenever you click on each test item, its test conditions will be shown in the test condition box. If you want to change the displayed item, click each test title in the test function box.

3.2.1.2 Test conditions

All test condition parameters such as start power, power step, number of power, and number of packets can be set up in the functions window.




Fig 3.11 Test Conditions for PER using RX1 and RX2 Window

Parameters for PER test using RX1 and RX2 Window

SCENARIO

This is the test scenario of the sensitivity test. In 'NORMAL_UL', DUT should send unconfirmed or confirmed uplink messages periodically and the Tester sends confirmed downlink messages and checks the flag of acknowledgement in DUT frames in order to count errors. In 'CERTI_ECHO', DUT should enter the test mode by the Tester's activation command and the Tester will use EchoRequest/EchoResponse in order to count errors. In 'CERTI_DL_CNT', DUT should enter the test mode by the Tester's activation command and the Tester will use DL_Counter value in order to count errors.

For Version 1.0.2/1.0.3, it supports NORMAL_UL, CERTI_ECHO, CERTI_DL_CNT

For Version 1.0.4, it supports NORMAL_UL only

PACKET_NUM

This is the packet number of tests at each test point. Increasing it the test result may have higher resolution but the testing time may become longer.

START POW

This defines the start value of POWER sweep.

STOP POW

This defines the stop value for POWER sweep (read only).

STEP POW

This defines the step value for POWER sweep.

NUM POW

This defines the number of power values for POWER sweep.

TARGET_PER

This is a parameter to set the user's target PER. The test sweeps fully in the range of POWER until DUT does not satisfy TARGET_PER.

TARGET_CH_MASK

This parameter encodes the channels usable for uplink access. A bit in the CH_MASK field set to 1 means that the corresponding channel can be used for uplink transmissions.

TARGET_DL_CH_00 ~ 07

This parameter redefines DL channel frequencies for sensitivity test. Tester will use the DL_CHANNEL_REQ MAC command to modify downlink channel frequencies.

DOWNLINK_SLOT

This is a parameter to select the RX window for testing the DUT.

TARGET_DR

This is a parameter to determine the DR by sending MAC commands before the Sensitivity Test starts. *LinkADRReq* will be sent in case of RX1 and *RXParamSetReq* will be sent in case of RX2.

DL_PACKET

This is a parameter to define the contents of downlink packets to be used in the 'NORMAL_UL' scenario.

FPORT

This parameter defines the FPort number of a user-defined MAC Command.

PAYLOAD_SIZE

This parameter defines the size of payload of a user-defined MAC Command.

PAYLOAD

This parameter defines the content of the payload in hexadecimal format.

Parameters of TX Power Test

MODE


It determines the test method of Power Measurement. If it is set at SYNC_TO_LINK, Power measurement is fully synchronized with Link Analyzer. Power Measure displays all Received packets while Link Analyzer is running. If it is set as SCENARIO, Power Measure function measures TX power of DUT using special scenarios which is selected by SCENARIO parameter.

SCENARIO

It has three different scenarios to activate DUT to measure power of DUT. NORMAL_UL scenario mode just receives any packet from DUT and measures the power. CERTI_DL_CNT scenario will set the DUT as Test mode at the beginning stage and measure the power of DL_counter packets from DUT. CERTI_CW scenario will set the DUT as Test mode and transmit CW_ENABLE MAC command to transmit CW signal by DUT and measure this CW signal power. If you are using RWC5020B, this scenario mode also measures CW frequency value.

For Version 1.0.2/1.0.3, it supports NORMAL_UL, CERTI_DL_CNT, CERTI_CW

For Version 1.0.4, it supports NORMAL_UL, CERTI_CW



a. Test condition for TX Power test using LoRa Signal b. Test condition for TX Power test using CW

Fig 3.12 Test Conditions for TX Power Test

UL_DR

This parameter is the requested data rate of End Device for uplink messages.

ADR_POWER

This parameter is the requested output power of End Device for uplink messages.

TARGET_CH_MASK

This parameter encodes the channels usable for uplink access. A bit in the CH_MASK field set to 1 means that the corresponding channel can be used for uplink transmissions.

#PKT

This parameter defines the minimum packet number for power measurement on each channel which is defined by TARGET_CH_MASK.

CW_TIMEOUT

This parameter indicates the timeout for CW transmission.

3.2.1.5 Tested Result

If you click on the [SENSITIVITY AND TX POWER - TABLE](#) title, you can see the test result summary table.

PERFORMANCE TEST SUMMARY									
DUT NAME		EDT_PERF_EU868							
REGION		EU_868							
PER USING RX1 WINDOW : PASS									
DR	Start	Step	Stop	Target	#Pkt	Criteria	Result	Verdict	
DR0	-129.0	1.0	-138.0	0.100	1	-133	-135.0/0.000	PASS	
DR1	-126.0	1.0	-135.0	0.100	1	-130	-133.0/0.000	PASS	
DR2	-125.0	1.0	-134.0	0.100	1	-129	-131.0/0.000	PASS	
DR3	-122.0	1.0	-131.0	0.100	1	-126	-128.0/0.000	PASS	
DR4	-119.0	1.0	-128.0	0.100	1	-123	-125.0/0.000	PASS	
DR5	-116.0	1.0	-125.0	0.100	1	-120	-122.0/0.000	PASS	
DR6	-112.0	1.0	-121.0	0.100	1	-115	-120.0/0.000	PASS	
DR7	-97.0	1.0	-106.0	0.100	1	-100	-101.0/0.000	PASS	
PER USING RX2 WINDOW : PASS									
DR	Start	Step	Stop	Target	#Pkt	Criteria	Result	Verdict	
DR0	-129.0	1.0	-138.0	0.100	1	-133	-136.0/0.000	PASS	
DR1	-126.0	1.0	-135.0	0.100	1	-130	-133.0/0.000	PASS	
DR2	-125.0	1.0	-134.0	0.100	1	-129	-131.0/0.000	PASS	
DR3	-122.0	1.0	-131.0	0.100	1	-126	-127.0/0.000	PASS	
DR4	-119.0	1.0	-128.0	0.100	1	-123	-125.0/0.000	PASS	
DR5	-116.0	1.0	-125.0	0.100	1	-120	-123.0/0.000	PASS	
DR6	-112.0	1.0	-121.0	0.100	1	-115	-119.0/0.000	PASS	
DR7	-97.0	1.0	-106.0	0.100	1	-100	-102.0/0.000	PASS	
TX POWER & FREQ TEST : FAIL									
POW	CH0	CH1	CH2	CH3	CH4	CH5	CH6	CH7	Verdict
0	-27.4								FAIL
1	-27.4								FAIL
2	-27.5								FAIL
3	-27.5								FAIL

Fig 3.14 Test Result – Summary Table

If you click on [PER using RX1 Window](#) you can see all tested results in detail in the result window from SF12 to SF7




Fig 3.15 Test Result – Detail Report

3.2.1.6 PER Performance test functionality condition

Synchronization PER test parameters between RX1 and RX2

When you check SYNC RX1/RX2, test condition parameters such as START, CRITERIA, STEP, #POW, #PKT, TARGET PER of RX1 and RX2 will be the same.

Test parameter value changing Unit

When you check 10, START and CRITERIA parameters will be changed in the 10dB unit when you change these values using arrow buttons. Without checking they will be changed in 1dB units.

Showing link message during test


When you check SHOW LINK MESSAGE DURING TEST, all link messages will be added in report.

[LINK MESSAGE]														
L	CH	SF	BW	POW	TIME	FCNT	Adr	Ack	B	FP	M	CMD		
U	0	7	125	11.6	REF	----	0	0	----	-	-	-	Join-request	Nonce=4195
D	0	7	125	-30.0	----	----	0	0	----	-	-	-	Join-accept	RX1DROffset=0, RXDela
U	2	12	125	11.8	7.80s	0000	0	0	-	002	U	DataUp	ByteLen=16	
D	2	12	125	-30.0	----	0001	0	0	-	224	U	ActivateTM		
U	1	12	125	11.9	8.44s	0001	0	0	-	224	U	DownlinkCounter	Cnt=0	
D	1	12	125	-30.0	----	0002	0	0	-	000	U	LinkADRReq	POW=1, DR=0, Mask=07h, N	
U	1	12	125	11.8	5.18s	0002	0	0	-	224	U	LinkADRAns	POW=1, DR=1, Mask=1	
D	1	12	125	-30.0	----	0003	0	0	-	224	U	EchoRequest	EchoLen=16	
U	0	12	125	11.8	5.35s	0003	0	0	-	224	U	EchoResponse	Echo PASS	
D	0	12	125	-132.0	----	0004	0	0	-	224	U	EchoRequest	EchoLen=16	
U	2	12	125	11.8	5.02s	0004	0	0	-	224	U	EchoResponse	Echo PASS	


Fig 3.16 Link Messages attached in Test Report

Showing graph

When you check SHOW GRAPH, it will show PER curve or TX power graph in report function window.



a. The result graph of PER test



b. The result graph of power test

Fig 3.17 Show Result Graph of PER and TX Power

3.2.1.7 Viewing Remote commands

If View SPY MSG is checked, it shows remote control commands and responses between the application and RWC5020x/5021x equipment.



Fig 3.18 Remote Message

3.2.2 LBT TEST

RWC5020x/5021x application provides LBT (listen before talk) test function. An RWC2020A is required for this test. In this test, RWC5020x/5021x application assumes an RWC2020A is connected as an interferer. Connect RWC5020x/5021x and RWC2020A with RS232 cable. RWC2020A will be controlled by RWC5020x/5021x through RS232 cable during LBT test. RWC2020A will make interference signals as you set up this RWC5020x/5021x application program. RWC2020A can make single or multi-interferer signals up to 8 at the same time. Users can check whether RWC2020A is connected or not with this  icon and message.

3.2.2.1 Checking the connection to RWC2020A

Users must check whether RWC2020A is connected or not before LBT test.

LBT test will not be run without RWC2020A LBT interferer.

3.2.2.2 Test Scenarios

The application provides two scenarios; channel and burst mode test.

In the channel mode test, RWC2020A transmits a single tone to each channel that users selected simultaneously. Users can set the test duration, reference power, and relative sub-channel power of RWC2020A interfering signals.

In the burst mode test, RWC2020A alternatively transmits multi-tones according to the time schedule. Users can set up the time duration of each signal burst.





Fig 3.19 LBT Scenario configuration window

3.2.2.3 Channel mode test

Users can configure the reference power and relative sub channel power of RWC2020A interfering signals. If you set channel relative powers the same as figure 3.20, RWC2020A will generate eight interference channels and set the absolute powers same as the values shown in the figure 3.20.



a. Relative channel powers

CH	CH00	CH01	CH02	CH03	CH04	CH05	CH06	CH07
Actual Power(dBm)	-79	-79	-79	-83	-79	-79	-79	-79

b. Absolute channel power table

Fig 3.20 LBT Channel power configuration

3.2.2.4 Burst mode test

In burst mode test, users can configure the power and the duration of each burst signal as well as test iteration. RWC2020A alternatively transmits two burst signals according to the power and duration.




Fig 3.21 LBT Burst channel configuration

3.2.2.5 Starting LBT test and result

Click on **RUN** and RWC5020x/5021x will start the communication with DUT and RWC2020A will generate an interference signal. While testing, RWC5020x/5021x will count up received packets per channel and display the result. The DUT shall not use channels whose interference signal is above the reference value.

3.2.3 NON-REGRESSION TEST

This test function is only for gateways, and it will be activated under the gateway type of DUT test.




Fig 3.22 Non-regression test control and parameters window

RWC5020x/5021x application program provides a new test method to verify gateway’s RF performance without an external network server, which is a part of non-regression tests for gateways defined by SEMTECH. You do not need to connect your gateway to any other network server because the RWC5020x application works as a network server. The test concept is shown in the fig 3.23.




Fig 3.23 Test concept of the Non-regression test with RWC5020x/5021x

Users need to connect the DUT with the RWC5020x/5021x measurement equipment, and RWC2020A interference signal if needed, and the PC that runs the RWC5020x/5021x application program acting as a server and a measurement controller, as shown in Figure 3.24 below.



Fig 3.24 The Concept of non-regression test of gateways

In order to let RWC5020x/5021x know the IP and the destination port of the gateway, users have to set them manually. You can select the network adapter which has the actual IP address of the RWC5020x/5021x application running.




Fig 3.25 The IP and PORT setup for non-regression test

Non-regression test consists of 5 automated test functions such as TX output power calibration, PER/RSSI/SNR, sensitivity, frequency error tolerance, CW interferer immunity test, and inter-modulation immunity.

RWC5020x/5021x application program provides minimal amount of server functionality to respond to the request from a gateway.

If you set the Show JSON PKT checked, a monitor box appears and shows all JSON packets transmitted and received during the test.

3.2.3.1 TX output power calibration

This function measures TX output power of the DUT (gateway) and shows the power properties and makes a property table.

In this test, the RWC5020x/5021x application program makes DUT transmit signal according to the setup power through LAN with JSON and RWC5020x/5021x equipment measures the TX power of the DUT. Users can use this function as a calibrator for gateways.

Users can set up power start, power step, number of powers, and number of packets.



Fig 3.26 Parameters for TX POWER CALIBRATION

Users cannot change stop power. It will be calculated according to the power start and power step values automatically.

3.2.3.2 PER/RSSI/SNR

This function measures the PER (packet error rate), reads and shows the RSSI(Rx Signal Strength Indication) and SNR(Signal to Noise Ratio) information from the gateway using JSON.

In this test, RWC5020x/5021x equipment transmits a LoRa signal and RWC5020x/5021x application asks the gateway for RSSI, SNR and the number of received packets. RWC5020x/5021x application calculates PER using

the number of packets that equipment sent and the number of packets that gateway received and shows the result graphically.

Power step is fixed at 1dB and Power range is also fixed.

The transmit payload is 'all zeros'. Users cannot modify the payload.




Fig 3.27 Parameters for PER/RSSI/SNR




Fig 3.28 The test result of PER/RSSI/SN

3.2.3.3 SENSITIVITY

This function measures the PER (packet error rate) with respect to the power and searches the sensitivity using the measured PER.

While testing, RWC5020x/5021x equipment transmits a LoRa signal and RWC5020x/5021x application asks the gateway for the number of received packets. RWC5020x/5021x application calculates PER using the number of packets that the equipment sent and the number of packets that the gateway received and shows the result graphically.

The power step is fixed at 1dB and power range is also fixed in range -140 to -100dBm.

Users may modify only the number of packets. More packets will make more reliable results.
 The transmit payload is 'all zeros'. Users cannot modify the payload.

SENSITIVITY and PER TEST PARAMETERS

PACKET POW STEP 1 dB

Fig 3.29 Parameters for SENSITIVITY




Fig 3.30 The test result of SENSITIVITY

3.2.3.4 Frequency error tolerance

This function measures the immunity properties with respect to the frequency error of the DUT (gateway) using the packet error rate. It is available only with RWC5020B and RWC5020M.

In this test, RWC5020B/M equipment transmits LoRa signal with frequency offset and RWC5020x/5021x application asks the gateway for the number of received packet and calculates PER using the number of packets that the equipment sent and the number of packets that DUT received. TX Power of RWC5020x/5021x is fixed at -100dBm and frequency offset step is fixed at 1.0 ppm. Users may modify the number of packets to be tested.

The transmit payload is 'all zeros'. Users cannot modify the payload.

FREQUENCY TOLERANCE PARAMETERS

PACKET

POWER -100.0 dBm

OFFSET STEP 1ppm

Fig 3.31 Parameters for FREQUENCY ERROR TOLERANCE




Fig 3.32 The test result of FREQUENCY ERROR TOLERANCE

3.2.3.5 CW immunity against the interferences with frequency offset.

This function measures the immunity properties of the gateway against interference signal of variant frequencies and powers.

In this test, RWC5020x/5021x equipment transmits LoRaWAN® signal as a wanted signal, RWC2020A transmits CW as an interference signal and RWC5020x/5021x application asks the gateway (DUT) for the number of received packet during the test.

CW INTERFERER PARAMETERS
RWC5020x Signal Generator

PAYLOAD # PACKET 10 TARGET PER 0.500

SIGNAL POWER SF7 -121.0 SF8 -124.0 SF9 -127.0 SF10 -130.0 SF11 -133.0 SF12 -136.0 dBm

SF8BW500 -136.0 dBm

Fig 3.33 CW Interferer test parameters

RWC5020x/5021x application finds the interferer power level of the PER that meets target PER while calculating PER using the number of packet gateway received. Users can set payload size, number of packets, target PER, and each power for each spreading factor respectively. The transmit payload is 'all zeros'. Users cannot modify the payload.

RWC2020A interferer generator is required to test CW interferer immunity shown in the figure 3.34.




Fig 3.34 The test result of CW Interferer Immunity

3.2.3.6 Functionality condition

Showing Result Values

When you check Show Result Values, all tested values will be shown in the result window. It can take a quite long time to display according to the result amount.

Showing JSON packets during test

When you check Show JSON PKT, you can see JSON packets sending and receiving between SERVER and the DUT(Gateway) during the test.

Skipping current testing item

If you click the [SKIP] button during the test, the application will mark the current testing item as untested and start testing the next SF item which is checked.

3.3 Link Analyzer

Using this function, you can monitor all operations of DUT and dump all link messages in user-friendly format from RWC5020x/5021x while linking with DUT.

Link analyzer consists of a Link message tool, script editor, and payload editor.

Using payload editor, users can send mac command(s) or user defined packets while linking.

In addition, using script editor addition, users can create a script and play it while linking. You can add or remove a group of commands named ACTION which includes single, multiple MAC commands, and user defined payload.




Fig 3.35 Link Analyzer

3.3.1 Saving link message

Click on  button in the link message window and RWC5020x/5021x will start dumping all link messages between RWC5020x/5021x and DUT line by line. Clicking on  button will stop RWC5020x/5021x from dumping. All link messages can be saved any time with time stamped file name by clicking  on button. When you click the [START SAVING] button, the program starts saving the link message in real time, shows the saving status with a progress bar, and you can see the file name. Change the naming option in the environment menu to specify the desired file name.

3.3.2 Payload editor

3.3.2.1 Sending Commands

You can edit MAC commands in the link script editor window. You can select single or multiple commands by checking one, two, or three SET . When multiple SET are selected, multiple MAC commands are added in a single frame. The maximum number of multiple MAC commands in a frame is limited to 3 on RWC5020x/5021x equipment.




Fig 3.36 Sending multiple commands in a single packet

When User Defined is checked, user definable command edit window will appear.




Fig 3.37 An Example for User defined commands in FOPTS and MAC PAYLOAD USER DATA

3.3.2.2 Malfunction test

Users can send the MAC commands which include errors intentionally inserted using malfunction. This function is also applied to GWT.




Fig 3.38 Malfunction status window in PAYLOAD EDITOR

Test Procedure

Activation – Start link analyzer and make an activation with DUT.

MAC command selection - Select a mac command referring 3.3.2.1

Malfunction Editing - Click the [SET] button in the MALFUNCTION area and select the types of error which you want to add like Fig 3.39. To generate an intentional MIC error, set MIC_ERROR to ON. To modify the MAC header part, set MHDR_ERROR to ON and configure the XOR_MHDR value. XOR_MHDR value is exclusive OR with MAC Header. To modify the Frame header part, set FHDR_ERROR to ON and configure the XOR_FHDR value. XOR_FHDR value is exclusive OR with Frame Header.




Fig 3.39 Malfunction configuration parameters

MAC command transmission - Clicking [SEND CMD] button will send MAC commands and malfunction setup commands to the equipment. Then RWC5020x/5021x will send the intentionally malfunctioned MAC command to the DUT.

3.3.2.3 MAC Commander Parameters

DOWNLINK_SLOT

When RWC5020x/5021x emulates Gateway/Server mode (EDT), it could respond to the uplink frame by downlink frame using RX1 window or RX2 window. Using this parameter, users can select the RX window for testing the DUT.



Fig 3.40 MESSAGE TYPE

MAC_CMD_TYPE

This parameter defines the type of MAC command to be transmitted: confirmed or unconfirmed.



Fig 3.41 COMMAND FILED

MAC_CMD_FIELD

This parameter defines the type of field where MAC command is stored in a frame: payload or option field.



Fig 3.42 RESPONSE TIME OUT

RESP TIMEOUT

This parameter defines MAC answer time-out after sending MAC command.



Fig 3.43 Response time out value

FOPTS_SIZE

This parameter defines the size of the FOpts field. This parameter is shown if MAC_CMD_FIELD is set as FOPTION.

FOPTS

This parameter defines the content of FOpts in hexadecimal format. This parameter is shown if MAC_CMD_FIELD is set as FOPTION.

MAC_CMD: DEV_STATUS

This parameter is for sending *DevStatusReq* command to DUT, which expects *DevStatusAns* command from it. *DevStatusReq* command requests the status of the End Device and does not have any parameters.

MAC_CMD: LINK_ADR

This parameter is for sending *LinkADRReq* command to DUT, which expects *LinkADRAns* command from it. *LinkADRReq* command requests the End Device to change data rate, transmit power, repetition rate or channel.

ADR_DR

This parameter is the requested data rate of End Device for uplink messages.

ADR_TXPOW

This parameter is the requested output power of End Device for uplink messages.

ADR_CH_MASK

This parameter encodes the channels usable for uplink access. A bit in the CH_MASK field set to 1 means that the corresponding channel can be used for uplink transmissions.

ADR_MASK_CTRL

This parameter controls the interpretation of the previously defined CH_MASK bit mask. It controls the block of 16 channels to which the CH_MASK applies. It can also be used to globally turn on or off all channels using specific modulation.

ADR_NB_TRANS

This parameter is the number of transmissions for each uplink message.

MAC_CMD: DUTY_CYCLE

This parameter is for sending *DutyCycleReq* command to DUT, which expects *DutyCycleAns* command from it. *DutyCycleReq* command sets the maximum aggregate transmit duty-cycle of the End Device.

MAX_DUTY_CYCLE

This parameter is used by the network coordinator to limit the maximum aggregate transmit duty cycle of an End Device.

MAC_CMD: RX_PARAM_SETUP

This parameter is for sending *RXParamSetupReq* command to DUT, which expects *RXParamSetupAns* command from it. *RXParamSetupReq* command sets the reception slots parameters.

RX1_DR_OFFSET

This parameter sets the offset between the uplink data rate and the downlink data rate used to communicate with End Device on the first reception slot (RX1).

RX2_FREQ

This parameter defines the frequency of a downlink using the second receive window.

RX2_DR

This parameter defines the data rate of a downlink using the second receive window.

MAC_CMD: TX_PARAM_SETUP

This parameter is for sending *TXParamSetupReq* command to DUT, which expects *TXParamSetupAns* command from it. *TXParamSetupReq* command is used by the network server to set the maximum allowed dwell time and Max EIRP of End Device, based on local regulations.

MAX_EIRP

This parameter corresponds to an upper bound on the device's radio transmit power. The device is not required to transmit at that power, but shall never radiate more than this specified EIRP.

Coded Value	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Max EIRP (dBm)	8	10	12	13	14	16	18	20	21	24	26	27	29	30	33	36

UL_DWELL_TIME

This parameter corresponds to the maximum allowed dwell time for uplink transmissions.

DL_DWELL_TIME

This parameter corresponds to the maximum allowed dwell time for downlink transmissions.

MAC_CMD: NEW_CHANNEL

This parameter is for sending *NewChannelReq* command to DUT, which expects *NewChannelAns* command from it. *NewChannelReq* command creates or modifies the definition of a radio channel.

NEW_CH_MODE

This parameter can be used to either modify the parameters of an existing bidirectional channel

or to create a new one. To create or modify the channel, set this parameter as 'CREATE'. To delete the channel, set this parameter as 'DELETE'

NEW_CH_INDEX

This parameter is the index of the channel being created or modified.

NEW_CH_MAX_DR

This parameter designates the highest uplink data rate allowed on this channel.

NEW_CH_MIN_DR

This parameter designates the lowest uplink data rate allowed on this channel.

MAC_CMD: DL_CHANNEL

This parameter is for sending *DIChannelReq* command to DUT, which expects *DIChannelAns* command from it. *DIChannelReq* command sets the network to associate a different downlink frequency to the RX1 slot.

DL_CH_INDEX

This parameter is the index of the channel whose downlink frequency is modified.

DL_CH_FREQ

This parameter is the corresponding downlink frequency value of a 24 bits unsigned integer. The actual downlink frequency in Hz is $100 \times \text{DL_CH_FREQ}$.

MAC_CMD: RX_TIMING_SETUP

This parameter is for sending *RXTimingSetupReq* command to DUT, which expects *RXTimingSetupAns* command from it. *RXTimingSetupReq* command sets the timing of the reception slots.

RECEIVE_DELAY

The first receive window RX1 opens RECEIVE_DELAY seconds after the end of the uplink modulation.

MAC_CMD: USER_DEFINED

This parameter is for sending a user-defined command to DUT, which includes user-defined data of user-defined length.

FPORT

This parameter defines the FPort number of a user-defined MAC Command.

PAYLOAD_SIZE

This parameter defines the size of payload of a user-defined MAC Command.

PAYLOAD

This parameter defines the content of payload in hexadecimal format.

MAC_CMD: CONFIRMED_TM

This parameter is for sending *Confirmed frames* command to DUT, which requests DUT to send the consequent uplink packets with a message type 'Confirmed'. It may be meaningful only after certification test mode is enabled by *Activate test mode* command.

MAC_CMD: UNCONFIRMED_TM

This parameter is for sending *Unconfirmed frames* command to DUT, which requests DUT to send the consequent uplink packets with a message type 'Unconfirmed'. It may be meaningful only after certification test mode is enabled by *Activate test mode* command.

MAC_CMD: ECHO_REQUEST_TM

This parameter is for sending *EchoRequest* command to DUT, which requests DUT to reply with *EchoResponse*. It may be meaningful only after certification test mode is enabled by *Activate test mode* command.

ECHO_LEN

This parameter indicates the length of payload in *EchoRequest* command.

PAYLOAD

This parameter defines the content of payload in hexadecimal format.

MAC_CMD: TRIGGER_JOIN_REQ_TM

This parameter is for sending *Trigger Join Request* command to DUT, which requests DUT to send *Join-request*. It may be meaningful only after certification test mode is enabled by *Activate test mode* command.

MAC_CMD: ENABLE_CW_MODE_TM

This parameter is for sending *Enable Continuous Wave Mode* command to DUT, which requests DUT to send continuous wave (CW) signal based on the values in the payload. It may be meaningful only

after certification test mode is enabled by *Activate test mode* command.

CW_TIMEOUT

This parameter indicates the timeout for CW transmission.

CW_FREQ

This parameter indicates the frequency of CW signal.

CW POW

This parameter indicates the power of CW signal.

MAC_CMD: BEACON_FREQ

This parameter is for sending *BeaconFreqReq* command to DUT, which expects *BeaconFreqAns* command from it. *BeaconFreqReq* command sets the network to associate new beacon frequency

BEACON_FREQ

This parameter is the corresponding beacon frequency value of a 24 bits unsigned integer.

MAC_CMD: PING_SLOT_CH_REQ

This parameter is for sending *PingSlotChannelReq* command to DUT, which expects *PingSlotFreqAns* command from it. *PingSlotChannelReq* command modifies the frequency and/or the data rate on which the end-device expects the downlink pings

PING_DR

This parameter is the index of the Data Rate used for the ping-slot downlinks.

PING_FREQ

This parameter is the corresponding ping channel frequency value of a 24 bits unsigned integer.

The actual ping channel frequency in Hz is $100 \times \text{PING_FREQ}$.

MAC_CMD: FORCE_REJOIN

This parameter is for sending *ForceRejoinReq* to DUT, which expects no answer from it. With the *ForceRejoinReq* command, the network asks a device to immediately transmit a Rejoin-Request Type 0 or type 2 message with a programmable number of retries, periodicity and data rate.

REJOIN_DR

This parameter is the data rate of Rejoin-Request.

REJOIN_TYPE

This parameter is the type of Rejoin-Request.

REJOIN_RETRY

This parameter is the total number of times DUT will retry Rejoin-Request.

REJOIN_PERIOD

This parameter is the delay between retransmissions. The actual delay is $32 \times 2^{\text{Period}} + \text{Rand32}$ seconds, where Rand32 is a pseudo-random number in the [0:32] range.

MAC_CMD: REJOIN_SETUP

This parameter is for sending *RejoinParamSetupReq* command to DUT, which expects *RejoinParamSetupAns* command from it. *RejoinParamSetupReq* command sets the network to request DUT to periodically send a *RejoinReq* Type 0 message with a programmable periodicity defined as a time of a number of uplinks.

REJOIN_MAX_TIME_N

This parameter is the max time T. DUT must send a Rejoin-Request Type 0 at least every 2^{T+10} seconds.

REJOIN_MAX_CNT_N

This parameter is the max count C. DUT must send a Rejoin-Request Type 0 at least every 2^{C+4} uplink messages.

MAC_CMD: ADR_SETUP

This parameter is for sending *ADRParamSetupReq* command to DUT, which expects *ADRParamSetupAns* command from it. *ADRParamSetupReq* command allows changing the ADR_ACK_LIMIT and ADR_ACK_DELAY parameters defining the ADR back-off algorithm.

ADR_LIMIT_EXP

This parameter is used to set ADR_ACK_LIMIT parameter value:

$$\text{ADR_ACK_LIMIT} = 2^{\text{ADR_LIMIT_EXP}}$$

ADR_DELAY_EXP

This parameter is used to set ADR_ACK_DELAY parameter value:

$$\text{ADR_ACK_DELAY} = 2^{\text{ADR_DELAY_EXP}}$$

3.3.3 Script editor

This function provides a method to create a scenario that sends mac commands sequentially. The scenario

consists of actions which include a single or multiple commands, information, and sleep time that creates wait times in between actions. Users can add, remove, or edit a single or multiple commands in an action and modify the wait time.

You can edit MAC commands in the link script editor window using buttons. 

3.3.3.1 Adding commands

In order to add an action, have SET checked with at least one command which you want to add. By clicking [add] button you can add commands and parameters in action format.

Script editor does not check if the commands are the same or not. It means the same commands could be added in single action. You must check whether it is intended or not by yourself.




Fig 3.44 Adding an action into Script Editor




Fig 3.45 Adding an action that includes two commands

The SLEEP function makes RWC5020x/5021x wait for a certain duration of time before sending the next command. The duration of wait time can be edited by the users.




Fig 3.46 Editing SLEEP time between actions

3.3.3.2 Moving commands

You can move actions up or down using   buttons. First, select an action and move it.




Fig 3.47 Moving an action.

3.3.3.3 Deleting actions

You can delete actions by clicking the [DEL] button. Script editor will not ask whether you want to delete it or not. Therefore, use the [DEL] button carefully to not delete any commands.




Fig 3.48 Deleting an action.

3.3.3.4 Renaming actions

You can edit the names of the actions or parameters and even commands.

Click the left mouse button to edit. The Application will not verify you whether they are actions, parameters or the commands. Rename very carefully not to rename the commands.



Fig 3.49 Renaming action title.

Define the PAYLOAD TYPE as UNCONFIRMED or CONFIRMED and define the CMD FIELD as PAYLOAD or FOPTION. You can verify what you selected from action's information `UNCONFIRMED|FOPTION|224`

3.3.3.5 Running actions

Clicking `Script Editor` `RUN` will make RWC5020x/5021x send MAC commands to DUT according to the script. Before running the script, RWC5020x/5021x must be in the running link analyzer. If it is not in the running link analyzer, the application will let RWC5020x/5021x run the link analyzer automatically while running the script.

[RUN] button will be activated after creating a project and DUT and connection with RWC5020x/5021x is complete. While running, it indicates the item that is being tested and shows tested results beside the commands that have been sent as follows.




Fig 3.50 Running script screen

3.3.3.6 Saving Script

You can save the script to keep what you have edited. After modifying your script, click and select a folder to decide where you want to save it.

3.3.3.7 Opening Script

You can recall the saved script you edited previously. Just click and select the saved script file.

3.4 Functions

It has four special functions such as MFG, NST SG(Signal Generator), NST SA(Signal Analyzer) and FUOTA TEST.

3.4.1 MFG (Manufacturing)

This function is for a quick test for manufacturing. It helps users measure PER and the TX power of DUT very fast and easily.

For this function, a special function has to be prepared in DUT first. In the special mode of DUT, transmitting MEAS_START_FLAG, counting packets, recognizing MEAS_STOP_FLAG, and transmitting three same report frames functions should be prepared.

For the DUT information, “user data” such as serial number can be added in the MEAS_START_FLAG packet.

Clicking on  will make RWC5020x/5021x start waiting for the MEAS_START_FLAG MFG from DUT.


3.4.1.1 Test concept

MEAS_START_FLAG packet transmitted from DUT will make RWC5020x/5021x start transmitting packets to DUT at the power specified by users. After transmitting the MEAS_START_FLAG, DUT must switch to RX mode to receive packets from RWC5020x/5021x and count the number of the packets received.

After transmitting all packets, RWC5020x/5021x will transmit a MEAS_END_FLAG packet that stops DUT from counting and report the number of received packets.

After receiving the MESA_END_FLAG from RWC5020x/5021x, DUT must transmit a report frame including the number of received frames three times within TIMEOUT time.

Whenever DUT transmits any frame RWC5020x/5021x measures the TX power of DUT and shows the averaged value after receiving report packets.



a. MFG procedure b. Requirement operation for DUT

Fig 3.51 Test scenario for manufacturing

3.4.1.2 Protocol Parameters

MODULATION

This parameter defines the modulation type of the MFG test

LoRa / FSK / CW.

NETWORK

This parameter indicates the type of LoRa network (synchronization word) to be used in LoRa modulation in the MFG test.

PUBLIC / PRIVATE

SF

This parameter defines the spreading factor of a LoRa test frame to be used in the MFG test. If this value is set as ANY, RWC5020x/5021x receives any kind of SF packet and applies this SF value for TX packets.

SF7 / SF8 / SF9 / SF10 / SF11 / SF12 / ANY

BW

This parameter defines the bandwidth of a LoRa test frame to be used in the MFG test.

125 / 250 / 500

CR

This parameter defines the coding rate of a LoRa test frame to be used in the MFG test, which is applicable only when DUT_TYPE is 'GATEWAY'.

4_5 / 4_6 / 4_7 / 4_8 / NO_CRC

TX POLARITY

This parameter defines the TX signal polarity.

NORMAL / INVERSE

RX POLARITY

This parameter defines the RX signal polarity.

NORMAL / INVERSE

PREAMBLE_SIZE

This parameter defines the preamble size of a LoRa test frame to be used in the MFG test.

2 to 255

PAYLOAD_SIZE

This parameter defines the size of payload of the LoRa test frame in the MFG test.

0 to 250

PAYLOAD

This parameter defines the content of payload in hexadecimal format in the MFG test.

Hex value

FM_DEVIATION

This parameter defines the FM deviation value for FSK modulation.

1 to 100 kHz

DATA_RATE

This parameter defines the data rate value for FSK modulation.

1.000 to 128.000 kbps

SYNC_WORD_SIZE

This parameter defines the Sync word size for FSK modulation

1 to 8

SYNC_WORD

This parameter defines the Sync word for FSK modulation

Hex value

REPEAT_NUM

This parameter defines the number of transmissions of a LoRa test frame to be used in the MFG test.

2 to 5000

INTERVAL

This parameter defines the time interval in the second unit between consecutive LoRa test frames to be used in MFG test.

0.5 to 1000 sec

PER_CRITERIA

This parameter defines the user's criteria of the result value of PER measurement in MFG test.

0.00 to 1.00

POW_CRITERIA_UPPER

This parameter defines the user's upper criteria of the result value of Power measurement in MFG test.

-50 to 30 dBm

POW_CRITERIA_LOWER

This parameter defines the user's lower criteria of the result value of Power measurement in MFG test.

-50 to 30 dBm

TIME_OUT

This parameter defines the timeout in the second unit until RWC5020x/5021x waits for a LoRa frame from DUT.

1 to 100 sec

3.4.1.3 RF Parameters

TX_POW

This parameter defines the output power of RWC5020x/5021x in dBm.

FREQ

This parameter defines the frequency of RWC5020x/5021x

PATH_LOSS

Users can set the path loss between the RF port of RWC5020x/5021x and DUT RF port. The measured power will be compensated with the defined path loss.

RX_GAIN

The RWC5020A/B has an AGC (Automatic Gain Control) function. So the RWC5020A/B will set appropriate RX gain after receiving a few packets from the DUT. This parameter defines the initial RX

gain when the Link is started. It is very important to set this parameter correctly to get the proper test result quickly. Set to LOW if the expected input level from your DUT to RWC5020A/B is higher than 15dBm. Set to HIGH if the expected input level is lower than -40dBm. Otherwise set it to MIDDLE.

HIGH / MEDIUM / LOW / LOWER(RWC5020M/B)

RX_GAIN_WARNING_TO

If RWC5020x/5021x does not receive RX packets for a while, RWC5020x/5021x assumes that RX_GAIN may be incorrect and displays a notification. This parameter defines the timeout period for this notification.

1 to 10000

RX_AGC

This parameter determines whether RX Gain is automatically adjusted or not

ON / OFF

3.4.1.4 Getting the result

Users can take measured results of the PER and the TX Power of DUT using remote commands.

Commands for

Reading the measured power of DUT :	READ:NST:MFG:POW?
Reading the measured PER of DUT :	READ:NST:MFG:PER?
Reading the user data in MEAS_START_FLAG frame :	READ:NST:MFG:DUT_INFO?

For all other remote commands, refer to the Remote Control Programming manual.

In figure 3.52, you can find an example test result with the MFG function. And refer to the application note RAN502004R6 for more detailed operation and application with MFG.




Fig 3.52 Example test using 4 DUTs(N=50, Target PER=0.1)

3.4.2 NST SG (Signal Generator)

Signal Generator is a function of transmitting the defined test waveform to DUT repeatedly. Three different modulations are provided: LoRa, FSK and CW.




Fig 3.53 NST SG parameters and report window

3.4.2.1 Protocol Parameters

MODULATION

This parameter defines the modulation type of Signal Generator

LoRa / FSK / CW.

NETWORK

This parameter indicates the type of LoRa network (synchronization word) to be used in LoRa modulation.

PUBLIC / PRIVATE

SF

This parameter defines the spreading factor of a LoRa test frame.

SF7 / SF8 / SF9 / SF10 / SF11 / SF12

BW

This parameter defines the bandwidth of a LoRa test frame.

125 / 250 / 500

CR

This parameter defines the coding rate of a LoRa test frame, which is applicable only when DUT_TYPE is 'GATEWAY'.

4_5 / 4_6 / 4_7 / 4_8 / NO_CRC

PREAMBLE_SIZE

This parameter defines the preamble size of a LoRa test frame.

2 to 255

PAYLOAD_SIZE

This parameter defines the size of the payload of the LoRa test frame.

0 to 250

PAYLOAD

This parameter defines the content of the payload in hexadecimal format.

Hex value

FM_DEVIATION

This parameter defines the FM deviation value for FSK modulation.

1 to 100 kHz

DATA_RATE

This parameter defines the data rate value for FSK modulation.

1.000 to 128 kbps

SYNC_WORD_SIZE

This parameter defines the Sync word size for FSK modulation

1 to 8

SYNC_WORD

This parameter defines the Sync word for FSK modulation

Hex value

TX_POLARITY

This parameter defines the TX signal polarity.

NORMAL / INVERSE

REPEAT_NUM

This parameter defines the number of transmissions of a LoRa test frame.

2 to 5000

INTERVAL

This parameter defines the time interval in the second unit between consecutive LoRa test frames.

0.05 to 1000 sec

3.4.2.2 RF Parameters

TX_POW

This parameter defines the output power of RWC5020x/5021x in dBm.

FREQ

This parameter defines the frequency of RWC5020x/5021x.

PATH_LOSS

Users can set the path loss between the RF port of RWC5020x/5021x and DUT RF port.

RWC5020x/5021x's real output power will be increased by this value to compensate for path loss.

3.4.3 NST SA (Signal Analyzer)

Signal Analyzer is a function of analyzing LoRa frames received from DUT repeatedly.




Fig 3.54 NST SA parameters and report window

3.4.3.1 Protocol Parameters

MODULATION

This parameter defines the modulation type of Signal Analyzer

LoRa / FSK / CW

NETWORK

This parameter indicates the type of LoRa network (synchronization word) to be used in LoRa modulation.

PUBLIC / PRIVATE

SF

This parameter defines the spreading factor of a LoRa test frame to receive. If this value is set as ANY, RWC5020x/5021x receives any kind of SF packets

SF7/SF8/SF9/SF10/SF11/SF12/ANY

BW

This parameter defines the bandwidth of a LoRa test frame to receive.

125/250/500

DATA_RATE

This parameter defines the data rate value for FSK modulation.

1.000 to 128kbps

CR

This parameter indicates the coding rate of a receiving LoRa test frame

CRC or NO_CRC

SYNC_WORD_SIZE

This parameter defines the Sync word size for FSK modulation

1 to 8

SYNC_WORD

This parameter defines the Sync word for FSK modulation

Hex value

RX_POLARITY

This parameter defines the RX signal polarity.

NORMAL / INVERSE

TEST_INTERVAL

It is updating time interval time during measuring CW in second unit.

1.0 to 100.0 sec

FCNT_AVG_N

The number of average while measuring frequency of receiving CW signal.

1 to 10

3.4.3.2 RF Parameters

TX POW

This parameter defines the output power of RWC5020x/5021x in dBm.

FREQ

This parameter defines the frequency of RWC5020x/5021x.

PATH LOSS

Users can set the path loss between the RF port of RWC5020x/5021x and DUT RF port.

RWC5020x/5021x's real output power will be increased by this value to compensate for path loss.

3.4.4 FUOTA Test

The application provides a special function for LoRaWAN® FUOTA test. RWC5020x/5021x emulates gateway/FDS and the application controls RWC5020x/5021x. The system block diagram is as follows




Fig 3.55 RedwoodComm test system for FUOTA Test

3.4.4.1 Test concept

Users can load the firmware binary file for the FUOTA test. The application fragments, encodes, and transmits

binaries to RWC5020x/5021x. Fragmentation parameters as well as Multicast parameters are editable using this GUI. The multicast function is optional. The clock Synchronization function will be performed automatically when Multicast function is selected.




Fig 3.56 FUOTA test parameters and report window

3.4.4.2 Fragmentation Parameters

INDEX

This value identifies one of the 4 fragmentation sessions possible simultaneously. RWC supports only one fragmentation at a time.

SIZE

This value is the size in byte of each fragment. The number of fragments will be calculated and displayed automatically.

ALGORITHM

The LoRa Alliance proposes LDPC as a simple Forward Error Correction (FEC) code to be used for fragmented transport of large binary files over LoRaWAN®.

DESCRIPTOR

This value is a freely allocated 4 byte field describing the file that is going to be transported through the

fragmentation session.

3.4.4.3 Multicast Parameters

OPTION

Select Unicast or Multicast method for FUOTA test.

Mc Key

Multicast Key value which will be distributed into the group of end-devices. The McAppSKey and McNetSKey are derived from the group's McKey.

Mc GroupID

An end-device may support being part of several multicast groups simultaneously. Therefore, all multicast related commands must always contain McGroupID of the multicast group being affected. RWC supports only one Multicast at a time.

Mc Addr

This value is the multicast group network address.

Mc Freq

This value is the frequency used for multicast.

Mc Addr

This value is the data rate used for multicast.

Mc Interval

This value is the interval between consecutive downlink messages within the multicast session to transmit user binary data.

3.4.4.4 Test Procedures

The message sequence charts are shown below for Multicast Test and Unicast Test respectively.




Fig 3.57 Multicast Test Procedure

IV. Report Functions

This chapter explains how to handle test reports for various kinds of test results. With report functions, users can see report messages while they test, create a report file after the test is finished and open it whenever users want to.

4.1 Report File Manager

4.1 Report File Manager

4.1.1 Creating Report

Clicking  will open the save file window. You can change the file name and save the result document.

The result file will be saved as a word document.  will be enabled on the Certification and Performance tab.




Fig 4.1 Creation of Test Report File

A Special report option will appear when the NON-REGRESS test tab is selected.




Fig 4.2 Report option menu for NON-REGRESS test

- w.r.t. Frequency** All NON-REGRESS test report will be created with respect to the tested frequency
- w.r.t. SF** All NON-REGRESS test report will be created with respect to the tested Spreading Factor
- w.r.t. Frequency and SF** All NON-REGRESS test report will be created with respect to both tested frequency and SF

After creating a report file, it will open automatically.




Fig 4.3 Created Report file (.doc)

4.1.2 How to Open the Saved Report File

Clicking will open a REPORT LIST window. Double clicking on a file name will open the selected file. The reading tool is Microsoft Word installed on your PC. This list window will show only the files existing on the same directory of DUT.




Fig 4.4 The List of test report files

Headquarters

#14008, OfficeSection Bldg, SK M-city, 195, Baengma-ro, Ilsandong-gu, Goyang-si, Gyeonggi-do, Korea
+82-70-7727-7011

Canada Branch

Suite 206, 3711 Delbrook Ave, North Vancouver, BC V7N 3Z4, Canada
+1-640-770-2688

E-mail support@RedwoodComm.com

Website <https://RedwoodComm.com/>
